

rozdávěč	obvod	místnosti - zařízení	kabel	celkem [kW]	zásuvky [ks]	vývody [ks]	jištění	délka [m]	poznámka	počet předřadníků (adres)
R3.5.1										
R3.5.1	MF1-1	3.027	1-CXKH-R 3x2,5		4		16C/1	20		
R3.5.1	MF1-2	3.027	1-CXKH-R 3x2,5		4		16C/1	20		
R3.5.1	MF1-3	3.027	1-CXKH-R 3x2,5		6		16C/1	20		
R3.5.1	MF1-4	3.027	1-CXKH-R 3x2,5		6		16C/1	20		
R3.5.1	MF1-5	3.027	1-CXKH-R 3x2,5		3		16C/1	20		
R3.5.1	U-11	3.027	1-CXKH-R 3x2,5		4		16C/1N	20		
R3.5.1	U-12	3.027	1-CXKH-R 3x2,5		4		16C/1N	20		
R3.5.1	U-13	3.027	1-CXKH-R 3x2,5		3		16C/1N	20		
R3.5.1	U-14	3.027	1-CXKH-R 3x2,5	2,85	1J		16C/1N	20		
								234		
R3.5.1	M-1	R3.5 - PŘÍVOD	1-CXKH-R 5x16				63B/3	20		
								26		
R3.5.1	MF-11	3.027	1-CXKH-R 5x2,5		1		16C/3	20		
								26		
R3.5.1	M-11	střecha	CYKY 3x2,5	1,25			16C/1	60	VZT2.01	
R3.5.1	M-12	střecha	CYKY 3x2,5	1,25			16C/1	60	VZT3.01	
								156		
R3.5.1	U-1	3.027	H07RN-F 3x6				40D/1	15	vývod stávající UPS	
R3.5.1	U-2	3.027	H07RN-F 3x6				40D/1	15	by-pass UPS	
R3.5.1	U-3	3.027	H07RN-F 3x6				40D/1	15	přívod stávající UPS	
R3.5.1	M-2							58,5		
R3.5.1	M-3									
R3.5.1	PA-11	rezerva								
R3.5.1	PA-12	rezerva								
R3.5.1	PA-13	rezerva								
R3.5.1	MF1-6	rezerva					16C/1			
R3.5.1	U-4	R3.5.1					40D/1		servisní by-pass v rozdávěči	